

Tool equipment for the home area

1) POCKET TOOLS

Insider 1 : Universal bit holder for bits 1/4" with integrated magazine for 8 PrecisionBits® C6
length of blade: 20 mm, total length: 125 mm; fits in every pocket to take along

Item:

PB 6460 Red



PB 6460 Blue



PB 6460 Yellow



PB 6460 Black



PB 6460 Red with long blade



Content:

Flat-blade screwdriver 2, 3
Phillips screwdriver 1 and 2
Torx screwdriver 10, 15, 20



Insider 2 and 3: Universal bit holder for 1/4" bits, with integrated magazine for 10 C6

PrecisionBits Item: PB 6510



PB 6510 R



With

Content:

Flat-blade screwdriver 3, 4
Phillips 2 and Pozidriv 2
TX screwdriver 10, 15, 20, 25
HEX screwdriver 3, 4



Tool equipment for the home area

2) Roll-up cases

The compact PB Swiss Tools roll-up cases are professional tool sets: For assembly and service work, for leisure time at home and on the road, they are indispensable companions.

Basic equipment for the most common screws

Item: Roll-up case PB 215

Content: Flat-blade screwdriver 0 – 5
Phillips screwdriver 1 and 2
square awl
With Classic interchangeable handle



Remark: The assortment covers the majority of screwdrivers for private use. The increased use of Phillips and Torx screws with additional transverse slot raises the flat-blade screwdriver to a universal (screwdriver) tool.

As an alternative to the roll-up case: ToolBox **PB 8215 Box**



Variants of roll-up case PB 9216 Red: Supplemented with the small flat-blade and Phillips screwdrivers up to size 00 (glasses, cameras, etc.)

Roll-up case PB 9215 Blue: Flat-blade screwdrivers starting at size 2, supplemented with hex keys (bikes) and voltage tester

All-rounder - 31 Tools in One

Universal screwdriver sets with interchangeable blades in a compact roll-up case

With the extensive blade assortment for all common types and sizes of screws, no screw remains untouched **PB 8515**

7 x

4 x

3 x

7 x

8 x

Ahle/awl/alêne

Voltage tester 110 - 250 V



Tool equipment for the home area

3) Wall bracket and sets:

With wall brackets and sets for the hobbies room or the studio, the most common tools are clearly arranged and ready at hand.

Minimum equipment:

Item number: Wall bracket PB 244

Content: Flat-blade screwdriver 1 - 4
Phillips screwdriver 1 + 2



Remark: These screwdrivers cover the largest demand for home and leisure time use.
The flat-blade screwdrivers are universal tools (scraper, lever, etc.). The increased use of Phillips and Torx screws with combo transverse slot also upgrades the flat-blade screwdrivers.
The PH screwdrivers can also be used as a provisional screwdriver for PZ screws in private use (professionals will often do it, too).



Item number: Wall bracket PB 440

Content: Torx screwdriver 8 - 25



Remark: Wood and furniture screws increasingly feature Torx profiles. While a cross-head screw can be handled with a flat-blade screwdriver – with high strength and durability – in a makeshift situation, there is no alternative for the Torx screws ... they need the correct screwdriver.



Item number: Holder PB 210 H-8

Content: Hex key 1.5 – 8 mm



Remark: For metal screws, e.g. on bicycles, skates, etc.



Tool equipment for the home area

For professionals at home

Item number: Wall bracket PB 240

Content: Flat-blade screwdriver 1 - 6



Remark: With the exception of watches, glasses or screws for optics, all slotted screws in the private area can be handled. The size 6 serves as a robust universal tool.

Item number: Wall bracket PB 242

Content: Phillips screwdriver 0 - 3



Remark: Suitable for practically all cross-head screws. Even PZ screws can be handled with these tools.

Item number: Wall bracket PB 243

Content: Pozidriv screwdriver 0 - 3



Remark: Many (older) wood screws feature a PZ profile. Users who often have to deal with these types of screws or for whom a perfect fit of the screwdriver is important, purchase this set.

Item number: Wall bracket PB 440

Content: Torx screwdriver 8 - 25



Remark: Wood and furniture screws increasingly feature Torx profiles. While a cross-head screw can be handled with a flat-blade screwdriver – with high strength and durability – in a makeshift situation, there is no alternative for the Torx screws ... they need the correct screwdriver.

Item number: Holder PB 212 LH-10 RB

Content: Hex key 1.5 – 8 mm



Remark: For metal screws, e.g. on bicycles, skates, etc. This set completes the assortment for performing all types of work with screws in "normal usage".



Tool equipment for the home area

Item number: Roll-up case PB 513

Content: Flat-blade screwdriver 00 + 0
Phillips screwdriver 00 + 0
Hex key wrench 1.5 – 3
Torx screwdriver 6 - 9
with telescopic handle



Remark: For all screw applications in "small areas," such as optics, watches, electronics.

Supplement to striking tools

Item number: Holder PB 850

BL Content: Center punches
PB 710/2

Drift punches PB 730/3, 4 flat chisels
805/12 and 18 cross-cut chisels 815/5

Version: Octagonal shaft, chrome-plated

Remark: For metal work involving center punching, loosening bolts up to countersinking nails.
The chisels can be used for metals as well as stone or even concrete.
The cross-cut chisel is used for grooves.



Complementing with third-part products

Complementing the listed tools from PB Swiss Tools with the following products allows almost a complete coverage of all hobby, assembly and upkeep work in the private area:

Cross peen mallet



Universal pliers



Open-end and box wrench set,
poss. socket wrench set

